



Worm Gear Set

material: brass, stainless steel

quantity: 1 worm and one spur gear



note: Take 1/2" of 1/4-20 brass all-tread rod, drill #28 and tap 8-32 clear through.. Place 1 drop of thread sealant (Loctite 290 or Superglue) inside hole. Screw in two 8-32x1/2" SS Allen set screws so they meet in middle. Tighten gently, too tight and brass will break. Hold brass in 1/4" collet chuck and turn SS set screws to give 0.135 diameters. Reduce length of brass to 0.495.



Steve Smith
Bustamante Group
phone 510-666-2761
steve@alice.berkeley.edu